

Download stc-isp6.86 von <http://www.stcmicro.com/rjxz.html>

1. Open the STC programming software
2. Insert the programming cable. Important to insert it after opening the software!
3. Select "Single Chip Microcomputer Type" : "IAP15W4K61S4" (which is under "STC15W4K32S4 Series");
4. Select the port that was assigned to your preferred USB-Serial Adaptor. You can find the port in the Device Manager
5. Change the settings, as per the attached image.
6. Press "Open Code File" to open the new firmware.
7. Link the controller to the programming cable (using the EB-BUS; one end of the EB-BUS is linked to the EB-BUS cable at the Max controller, and the display cable at the other end of the EB-BUS is linked to the programming cable);
8. Link the motor to the battery, but do not turn on the battery power;
9. Press "Download/Program";
10. Power on the battery.
11. You should see the green progress bar scroll across if it is successful.
12. Only when is showing "Complete ! (date)" it is done properly

