



Note: Controller connections
 K6 - LH socket A - Controller / PC joystick
 Controller mode: 2=Data 3=Latch 4=Clock 6+= 8=GND
 PC mode: 1=Up 2=Dn 3=Left 4=Right 6=Trig/Fire 7+= 8=GND
 5=ADC0 9=ADC1
 If JS1 is installed then it replaces Port A
 VRx=GP26 VVy=GP27 SW=GP14
 K7 - RH socket B - Controller / Joystick/Networking
 Controller mode: 2=Data 3=Latch 4=Clock 6+= 8=GND
 (9=ADC2)
 PC mode: 1=Up 2=Dn 3=Left 4=Right 6=Trig/Fire 7+= 8=GND
 LB3 linked. ADC not available. Do not connect pin 9.
 Network mode: 2=COM2_TX 3=COM2_RX 8=GND

Title PicoGame NES Version 2.0		
Author Mixel90		
File C:\Users\Mick\Dropbox\Pic ... PicoGame 20.dsn		
Revision 0		
Date 5/7/22		
Sheets 1 of 1		